INTRODUCTION TO THE TABLE OF MARKINGS, LABELS AND PLACARDS


USE THIS TABLE ONLY WHEN THE ID NUMBER OR PROPER SHIPPING NAME IS NOT AVAILABLE.


This section displays the placards used on transport vehicles carrying hazardous materials/ dangerous goods with the applicable reference GUIDE circled. Follow these steps:

1. **Approach scene from upwind, uphill and/or upstream at a safe distance to safely identify and/or read the placard or orange panel. Use binoculars if available.**
2. **Match the vehicle placard(s) with one of the placards displayed in this section.**
3. **Consult the circled guide number associated with the placard. Use that guide information for now. For example:**


   - Use GUIDE **127** for a FLAMMABLE (Class 3) placard 
   - Use GUIDE **153** for a CORROSIVE (Class 8) placard 
   - Use GUIDE **111** when the DANGER or DANGEROUS placard is displayed or the nature of the spilled, leaking or burning material is not known. Also use this GUIDE when the presence of hazardous materials/dangerous goods is suspected but no placards can be seen.

   If multiple placards point to more than one guide, initially use the most conservative guide (i.e., the guide requiring the greatest degree of protective actions).
4. **Guides associated with the placards provide the most significant risk and/or hazard information.**
5. **When specific information, such as ID number or proper shipping name, becomes available, the more specific Guide recommended for that material must be consulted.**
6. **A single asterisk (*) on orange placards represents an explosive's compatibility group letter. The asterisk must be replaced with the appropriate compatibility group letter. Refer to the "Glossary" section.**
7. **Double asterisks (**) on orange placards represent the division of the explosive. The double asterisks must be replaced with the appropriate division number.**







For Divisions 1.1, 1.2, 1.3 and 1.5, enter division number (**) and compatibility group letter (*), when required.



For Divisions 1.4 and 1.6, enter compatibility group letter (*), when required.

















AND INITIAL RESPONSE GUIDE TO USE ON-SCENE


USING THE SHIPPING PAPER, NUMBERED PLACARD, OR ORANGE PANEL NUMBER

























138 Lithium metal batteries (UN3090, UN3091)

147 Lithium ion batteries (UN3480, UN3481)



